



2816 Centennial Road
Salina, KS 67401

785-825-6166

E-Mail – sales@innovatorswest.com

Ford Mod Motor Supplemental Install Instructions



Installation Notes:

Overdrive dampners may require grinding on the factory crank sensor mounting boss for clearance (see picture below).

The factory bolt is torque to yield and should only be used one time. Make sure to apply some red Loctite to the supplied crank bolt prior to tightening to 90 ft-lbs.

An 8-Rib dampner may be used on a 6-rib accessory drive if an upgrade to an 8-rib drive system is planned in the future.

DO NOT remove the hub from the dampner case. Install as a complete assembly!



Pictures of the modified crank sensor mounting boss



If you have purchased an overdrive dampner, measure over 3.800" (4.140" on 18% OD dampners) from the center of the crankshaft and make a mark on the crank sensor mounting boss. This mark will indicate how much of the boss must be removed for proper clearance. The boss must be ground down to within .070" of the surface of the timing cover for proper clearance on the rear of the dampner. We also suggest checking the height of the factory TDC and 10* timing marks higher up on the cover and reducing the height of these cast in marks as needed.